

Partslist FX Monsoon

Location	Article number	Description	Location	Article number	Description
A1	18025	Outer tube v6	H7	2500	Screw M3x6
A2 - 4,5	16017-1	Airtube 390 (drilled)	H8	11015	Trigger adjuster 2-stage
A2 - 5,5	16017-2	Airtube 390	H9	2020	Trigger
B1 - 4,5	2633	Barrel 4,5	I1	11624	O-ring 22x2,5 NBR70
B1 - 5,5	2629	Barrel 5,5	I2	18017	Valve offset
C1 - 4,5	17023	Muzzle 4,5	I3 - 4,5	18011	Valve spring lid 4,5
C1 - 5,5	17000	Muzzle 5,5	I3 - 5,5	18037	Valve spring lid 5,5
C2	10823-1	Plastic Pipe Short Split	I4	10630	Spring 0,5x5x40
C3	18033	Spring 1,5x16x65	I5	2040	Valve Seal
C4 - 4,5	18022	Spring guide 4,5	I6	2041	Valve Seal Holder
C4 - 5,5	18021	Spring guide 5,5	I7	2022	Mail valve stem
C5	10823-2	Plastic Pipe Short Hole	I8	2528	O-ring 1,5x1 NBR70
C6 - 4,5	10837	Washer Reloading 4,5	I9	2023	Valve Seat
C6 - 5,5	18040	Washer Reloading 5,5	I10	2529	O-ring 4,3x1,5 NBR70
C7	10823-2	Plastic Pipe Short Hole	I11	16028	O-ring 12x1 NBR70
D1	2534	Screw M5 x 6	I12	18014	Main Valve Housing
D2	2534	Screw M5 x 6	I13	5104	O-ring 9,3x2,4 NBR70
D3	5109	O-ring 11,6x2,4 NBR 70	J1	11017	Air tube end Inlet Nut
D4	18016	Brass bushing	J2	2524	Spring 0,5x3x20
D5	18019	Spring for Reloading	J3	12011	Inlet Valve
D6	18024-2	Plastic 16 Pipe Short	J4	5111	O-ring 2,5x1,5 NBR90
D7	5100	O-ring 23x1 NBR90	J5	18031	O-ring 28x1 NBR70
D8	2534	Screw M5 x 6	J6	18018	Barrel support ring
D9	2534	Screw M5 x 6	J7	18031	O-ring 28x1 NBR70
D10	5100	O-ring 23x1 NBR90	J8	11624	O-ring 22x2,5 NBR70
D11	2534	Screw M5 x 6	J9	11029	Air Cylinder End Inlet
D12	18013	Brass Air Bushing	J10	2637	Screw M4x6
D13	10828	Piston Ring	J11	11506	Screw M3x30
D14	18015	Reloading Piston	J12	12036	Barrel support base
D15	18024-1	Plastic 16 Pipe Long	K1	18035	Reloading rod
D16	18012	Steel bushing	K2 - 4,5	18006	Pellet probe 4,5
E1	-	Stock	K2 - 5,5	18007	Pellet probe 5,5
F1	5112	O-ring 5,28x1,78 NBR70	K3	18044	Rotating spring
F2	5112	O-ring 5,28x1,78 NBR70	K4	18008	Bolt attachment
F3	18034	Screw M6x45	K5	18005	Probe and hammer aligner
F4 - 4,5	18000	Barrel housing 4,5	K6	11023	Hammer
F4 - 5,5	18001	Barrel housing 5,5	K7 - 4,5	18029	Hammer weight 4,5
F5	16023	Steel pin 2x16	K7 - 5,5	18030	Hammer weight 5,5
F6	-	Piano wire trigger	K8	18038	Hammer spring
F7	16023	Steel pin 2x16	K9	17006	Hammer adjuster
G1	-	Reset pin v6	K10	18004	Cocking bolt
G2	18002	Reset axle	K11	2527	Screw M3x10
G3	12035	Screw M2,5x2,5	K12	18005	Probe and hammer aligner
G4	17018	Spring 0,2x3x15	L1	2528	O-ring 1,5x1 NBR70
G5	17040	Reset screw M3	L2	2528	O-ring 1,5x1 NBR70
G6	2637	Screw M4x6	L3	18003	Safety rod
H1	11525	Trigger Wheel	L4	2035	Short Handle
H2	17017	Trigger Base	M - 4,5	Separate list	Only 4,5 (regulator)
H3	2500	Screw M3x6	N1,2	2501	Screw M4x6
H4	2527	Screw M3x10	N3	2503	Screw M5x8
H5	18009	Trigger Sear	N4	-	Empty Hole
H6	17046	Spring 0,5x3,5x15	N5		Stock Screw

